

Wireless Keyboard

BK05

User Manual

Package Contents

- 1 x Foldable Kevboard
- 1 x USB-C Cable (both for charging and wired connection)
- 1 x Stand Holder for Smartphone and Tablet
- 1 x User Manual

Specifications

Connection Type	USB Wired + Bluetooth 5.1		
Key Numbers	78		
Backlit Keys	Not Backlit Version		
Dimensions-open	291 x 117 x 8.25 mm		
Dimensions-fold	166 x 120 x 14.80 mm		
Connected Devices	Up to 4		
Layout Compatibility	Windows/Mac		
Lithium Battery Capacity	300 mAh		
Charge Time	2h / 90 Days Working / USB-C Charge		
Sleep Time	30 Minutes		
Material	ABS (Front) + Aluminum Frame		
Key Structure	Scissor Switch		
Frequency Band	2402MHz - 2480MHz		
Maximum Transmission Power	0 dBm		

Indicator Overview

Power Indicator Status Indicator Caps Lock Indicator

Power Indicator:

- ---unfold the keyboard to power it on, and the indicator will be on for 3s. ---to check the battery status by pressing "fn" + "T", each flahes means 25%
- ---to display the charging status: stay in red when charging and turn green after fully charged.

State Indicator:

- ---to indicator Bluetooth channel by pressing "fn" + "Q/W/E", and the indicator
- ---to indicate the pairing status by press "fn" + "Z", and the indicator will keep flashing blue.

Caps Lock Indicator:

press the "caps lock" key to switch between uppercase and lowercase. ---when the indicator is on, works as uppercase letters

(may not work for Android).

---when the indicator is off, works as lowercase letters.

Guide to Use

USB Wired Connection

Step 1. Unfold the keyboard to power it on.

Step 2. Connect the included USB-C cable to BK05 and your computer. Step 3. Press "fn" + "R" to wired connection mode and ready to use.

Bluetooth Connection

A. How to pair with Bluetooth devices?

Pair with the 1st device

Step 1. Unfold the keyboard to power it on, and the Power indicator will be on for 3s

Step 2. Press "fn" + "Q" to Bluetooth channel 1, and the State indicator will flash once.

Step 3. Press "fn" + "Z" to Bluetooth pairing mode, and the State indicator will keep flashing,

Step 4 Find "iClever BK05S Keyboard" and click to connect it and the indicator will be off after successfully paired.

How to find BK05S in different system, please check below:

► For Windows 10:

Click Win > Setting > Devices > Bluetooth & other devices > Add Bluetooth or other device > Bluetooth > Find "iClever BK05S Keyboard" to connect.

► For Mac (MacBook/iMac):

Click System Preferences > Bluetooth > Click "iClever BK05S Keyboard" to connect.

► For iOS (iPad/iPhone) and Android:

Click Setting > Bluetooth > Click "iClever BK05S Keyboard" to connect.

- ---the Bluetooth pairing name may be shown as Keyboard icon. ---if fail to connect, please remove the "iClever BK05S Keyboard" name from
- your Bluetooth list, on your device turn off the Bluetooth and turn on it again to refresh.
- ---keep the keyboard and your device in 30cm in Bluetooth pairing.
- ---each channel can pair with 1 device (4 channels in total). ---auto re-connect function: the keyboard will connect with the last-used
- device automatically.
- ---do not connect it via a Bluetooth adapter.

Pair with the 2nd device

Step 1. Press "fn" + "W" to Bluetooth channel 2.

Step 2. Press "fn" + "Z" to Bluetooth pairing mode.

Step 3. Find "iClever BK05S Keyboard" and click to connect it.

Pair with the 3rd device

Step 1. Press "fn" + "E" to Bluetooth channel 3.

Step 2. Press "fn" + "Z" to Bluetooth pairing mode.

Step 3. Find "iClever BK05S Keyboard" and click to connect it.

B. How to switch among the connected devices?

Press "fn" + "Q/W/E/R" to switch between the connected devices.

Step 1. Press "fn" + "Q/W/E" to choose the Bluetooth channel 1/2/3 that vou want to re-pair.

Step 2. Press "fn" + "Z" to re-pair AGAIN.

Step 3. Find "iClever BK05S Keyboard" and click to connect it.

Keys and Functions

The table below describes special key combinations for different operating systems.

Function Keys	iOS&Mac OS	Android	Windows 10	Mac OS	Windows
Way to use	Press directly	Press directly	Press directly	Press fn +	Press fn +
* F1	Brightness -	Brightness -	Brightness -	F1	F1
* F2	Brightness +	Brightness +	Brightness +	F2	F2
	Home-iOS Mission Control-Mac	Home	Web Browser	F3	F3
Q F4	Search	N/A	Search	F4	F4
© _{F5}	Emoji-Mac N/A-iPhone&iPad	N/A	Emoji	F5	F5
H4 F6	Previous track	Previous track	Previous track	F6	F6
F7	Play/pause	Play/pause	Play/pause	F7	F7
F8 F8	Next track	Next track	Next track	F8	F8
₫× F9	Mute	Mute	Mute	F9	F9
۵> F10	Volume -	Volume -	Volume -	F10	F10
40 F11	Volume +	Volume +	Volume +	F11	F11
F12	Screenshot	Screenshot	Screenshot	F12	F12

Special Key Description Press "fn" + "esc" keys to turn on/off fn lock function. Your keyboard has by default access to the Media and Hotkeys such as Volume Down, Volume Up, Play/Pause, and so on. If you prefer to have direct access to F-keys, simply press "fn" + "esc" keys to swap The "fn" key is used in combination with other keys to access special Press "fn" + "del" to work as screen lock. NOTE: not works for Android device. It works as Virtual Keyboard NOTE: works for iPad/iPhone only. Switch Channel: press "fn" + "Q/W/E" to channel 1/2/3. Bluetooth Pairing: press "fn" + "Z" to Bluetooth pairing mode. Press "fn" + "R" to wired connection mode Check the battery by pressing "fn" + "T". One flash means 25% of the battery is left, 2 flashes means 50%, 3 flashes means 75%, and 4 It works as "win" when your system is Windows It works as "option" when your system is iOS or Mac OS. It works as "alt" when your system is Windows or Android. It works as "command" when your system is iOS or Mac OS. It works as "ctrl" when your system is Windows or Android. It works as "option" when your system is iOS or Mac OS. Press "fn" + "pg home and end. Press "fn" + "pg up/pg dn/home/end" to work as page up, page down,


System Requirements

- ▶ iOS 9.0 or later iPhone/iPad
- ▶ macOS 10.12 or later Mac/iMac
- ► Windows 8 or later with Bluetooth HID Profile PC/laptop/tablet
- ► Android 6.0 or later smartphone

NOTE: not fully compatible with, Bluetooth adapter, Mac mini, Samsung Smart TV, and Nokia phones.

Balance Stand

Open the two-sided blance stand to keep the flat typing



Charge the Keyboard

Charge the device with the included USB-C cable. ---- Output: DC 5V/200mA; USB charger is not included.

NOTE: do not use a charger with a voltage higher than 7 to charge the keyboard, and the keyboard will stop charging to protect the keyboard.

Tips

Keep away from oil, chemical, liquid, and snacks. Keep away from sharp objects.

Keep away from metal and other sources of wireless signal.

For more questions, please contact us by support@iclever.com

FAQ

Q. Delay when typing, stop working, and frequently get disconnected.

- 1. Restart your Bluetooth device.
- 2. Charge the keyboard for 2 hours.
- 3. Make sure that iClever device and your device are within close proximity of each other.

4. Try moving away at least 8 inches from:

- ---- Any device that could emit wireless waves: Microwave, cordless phone.
- baby monitor, wireless speaker, garage door opener, WiFi router --- Computer power supplies, Metal or metal wiring in the wall
- 5. Do not use your wireless keyboard on metal surfaces.
- 6. Check your computer memory, insufficient memory may cause the delay.
- 7. Try on a different APP/device to connect 8. Contact us to get advanced troubleshooting.

Q. Fails to connect.

- 1. Charge the keyboard for 2 hours.
- 2. Make sure that your iClever device and computer are within close proximity of each other.
- 3. Try moving away at least 8 inches (20 cm) from metal and other sources of wireless signal.
- 4. Delete all the Bluetooth connection records.
- (for example, for iPad, click "Settings" > "Bluetooth" > under "MY DEVICE" to delete all the Bluetooth connection records) 5. On your device, turn off the Bluetooth and turn it on again to Refresh.
- (For example, for iPad, click "Settings" > "Bluetooth" > if the on-screen switch beside Bluetooth currently shows as ON, tap it twice to refresh it) 6. Connect it again.

Q. It is not flat when typing on the desk.

Please open the two-sided of balance stand when typing on the flat desk.

Q. How to fix keyboard typing multiple letters on Mac?

- 1. On a Mac, choose the Apple menu > "System Preferences", click "Keyboard", and choose the Keyboard tab.
- 2. Locate the "Key Repeat" slider setting and adjust it to the "Off" position.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the Instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ----Reorient or relocate the receiving antenna.
- ----Increase the separation between the equipment and receiver.
- ----Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ----Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

iclever

Clavier sans fil

BK05

Manuel de l'Utilisateur FR

Instructions de couplage

Connexion filaire USB

Étane 1 Dépliez le clavier pour l'allumer

Étape 2. Connectez le câble USB inclus au BK05 et à votre ordinateur.

Étape 3. Appuyez sur « fn » + « R » pour passer en mode de connexion filaire et prêt à l'emploi.

Connexion Bluetooth

Étape 1. Dépliez le clavier pour l'allumer et le voyant d'alimentation sera allumé pendant 3 secondes

Étape 2. Appuyez sur « fn » + « Q/W/E » pour choisir le canal Bluetooth 1/2/3, et l'indicateur d'état clignotera une fois

Étape 3. Appuyez sur « fn » + « Z » pour passer en mode de couplage Bluetooth et l'indicateur d'état continuera à clignoter. Étape 4. Recherchez « iClever BK05S Keyboard» et cliquez pour le

connecter, et l'indicateur s'éteindra une fois l'appairage réussi.

IC Caution

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présentappareilestconforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitationestautorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareildoit accepter tout brouillageradioélectriquesubi. mêmesi le brouillageest susceptible d'encompromettre le fonctionnement.