

# 2.4G Keyboard

User Manual

## Package Contents

- 1 x 2.4G Numeric Keypad
- 1 x USB-C Charging Cable
- 1 x USB Receiver
- 1 x USB-A to USB-C Adapter
- 1 x User Manual

#### Specifications

Connection	2.4Ghz
Dimensions	131.9*88.8*19.72mm
Operating Range	<10m / 32.8ft
Product Weight	100g
Uninterrupted Work Time	55 hours
Charge Time	1 hour
Lithium Battery Capacity	100mAh
Lithium Battery Life	3 years

- \*Frequency band: 2405MHz-2470MHz
- \*Maximum transmission power: 0 dBm

### **Product Overview**

- Power Indicator. lights up for 2 seconds when powers on, and then turns off.
- ② Charging Indicator: stays in red when charging, and then turns green after fully charged.
- ③ Numeric Indicator: press "numlk" key to turn on/off the number lock function (not work for Mac).

If your system is Windows.

when the indicator is on, 0.123456789 works as normal.
when the indicator is off, 0.123456789 works as the function labeled on the key, such as ins, del, and end.

4 Charging Port: used for charging.



## Pairing Instruction

#### For Windows PC/laptop Users:

- Step 1. Slide the power switch to "ON" to power on.
- Step 2. Plug the USB Receiver into the computer USB-A port.

#### For MacBook/iMac Users:

- Step 1. Slide the power switch to "ON" to power on.
- Step 2. Plug the USB Receiver into "USB-A to USB-C Adapter" for ready to connect USB-C port devices.
- Step 3. Plug it into the MacBook or iMac.

USB Receiver

USB-A to USB-C Adapter

## **Charging Instruction**

Use the cable in the package to connect to the USB port of your computer.

We recommend directly connecting to the computer. If you want to use a charging adapter, please make sure its voltage is lower than 5V.

Output: DC 5V / 200mA; Charging adapter is not included.

# System Compatibility

Windows XP/Vista/7/8/10.

Mac OS X 10.10 or late MacBook/iMac

Note: if your MacBook is USB-C port, please connect the USB Receiver by "USB-A to USB-C adapter".

# Keys or keyboard stopped working

- 1. Use compressed air to clean the button.
- Make sure that plug the 2.4G receiver directly into a computer port instead of an external hub, or a KVM-similar.

- Keep the keyboard within the proximity of the receiver.
   If the receiver is placed at the back of the computer,
   please move it to the front for the reason that the signal may be blocked by the case.
- 4. If any, remove all receivers from the computer except for the iClever receiver.
- 5. Charge the keyboard for 1 hour.
- 6. Try plugging into different USB ports.
- Try plugging into a different computer to verify the issue.
   If the issue isn't resolved, please contact us for advanced solutions.

## Customer Service

support@iclever.com

## **FCC Statement**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- -Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interfer ence, and (2) this device must accept any interference received, including interference that may cause undesired operation.

-1-

-2-

-3-

-4-

-5-